



ADJUSTMENT PROCEDURE

1. AFTER INSTALLATION OF CABLE TO THE ENGINE BRACKET AND THROTTLE IDLER LEVER, CHECK TO ASSURE THAT THE CABLE SLIDER IS IN THE ZERO OF FULLY RE-ADJUSTED POSITION (IF NOT, REFER TO THE RE-ADJUSTMENT PROCEDURE).
2. ROTATE THE THROTTLE IDLER LEVER TO THE "FULL TRAVEL STOP" POSITION.
3. SLIDER MUST MOVE (RATCHET) TOWARD LEVER WHEN LEVER IS ROTATED TO "FULL TRAVEL STOP POSITION".
4. RELEASE LEVER

RE-ADJUSTMENT PROCEDURE

1. DEPRESS AND HOLD METAL RE-ADJUSTMENT TAB.
2. MOVE SLIDER BACK THROUGH FITTING IN DIRECTION AWAY FROM THROTTLE IDLER LEVER UNTIL SLIDER STOPS AGAINST FITTING.
3. RELEASE RE-ADJUSTMENT TAB.
4. REPEAT STEP 2 & 3 OF ADJUSTMENT PROCEDURE.

G20014-7A2

Fig. 7 T.V. Cable (RPO's - LB9 and L98)